

MOBILE LOCKER



Read this manual carefully and never store it inside the Mobile Locker!

Mobile Locker

PACKAGE CONTENTS

- 1 – Mobile Locker
- 1 – Operation Manual
- 1 – Tether cable
- 1 – ID Tag
- 1 – Removable shelf

DO NOT RETURN MOBILE LOCKER TO STORE!

For missing parts or difficulty operating your Mobile Locker, please contact our Consumer Assistance Department by telephone.

Store will not accept returned products without prior authorization. You must first contact our consumer assistance department.

US/Canada 1-877-354-5457 (Toll Free)
Australia 0011-800-5325-7000 (Toll Free)
Germany 00-800-5325-7000 (Toll Free)

PRODUCT OVERVIEW

- A - Mobile Locker body
- B - ID tag
- C - Mobile Locker door
- D - Combination dial
- E - Open/Close latch
- F - Charger cord hole
- G - Tether cable hole
- H - Pull-out shelf
- I - Tether secure knob



CAUTION!

OUTDOOR USE RESTRICTION

Although this item is great for securing personal items, it is not designed to be waterproof or to protect the contents from any other outdoor elements. Do not place Mobile Locker where rain or water spray can get to it and do not place in standing water.

SETUP & OPERATION

OPEN THE MOBILE LOCKER AND RESET PASSCODE
The preset factory Entry Code is "0000"

1. Set the dial so that it displays "0000".



2. Rotate locking latch to the open position and pull door open.



3. To program a new Personal Entry Code, Locate the switch on the back of the locker door and set it to the "Set Code" position.



4. Set the number dials on the front of the door to your new 4-digit Personal Entry Code and return the switch on the rear of the door to the "On" position.



IMPORTANT: If your Personal Entry Code is forgotten, entry into the Mobile Locker cannot be done without damaging the unit. Therefore, it is recommended to use a code that will be easily remembered like a birthdate.

IMPORTANT: Make a note of your new Entry Code and store in a safe place.

____ _
To re-open your Mobile Locker repeat steps 1-2 using your new Personal Entry Code instead of "0000".

SETUP & OPERATION CONTINUED

LOCK THE MOBILE LOCKER:

1. Push the door closed and rotate locking latch downward into the locked position.
2. Set dials back to "0000" to complete locking procedure.



MODEL 1550 - ATTACHING SECURITY CABLE


1. Un-screw the tether secure knob and remove the tether cable by pulling it through the hole.



2. Wrap cable around object and back through looped end.



3. Re-insert the tether through the hole and attach using the tether secure knob.




4. Close and lock the Mobile Locker.



ID TAG USE

1. Write phone number and name on ID tag
2. Insert ID tag in slot on the inside of the door
3. Information will be visible through front window



LIMITED WARRANTY

LH Licensed Products, Inc., ("LHLP, Inc.") warrants that for a period of one (1) year from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser's sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value.

THIS IS YOUR EXCLUSIVE WARRANTY.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty service.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.



Manufactured by
LH Licensed Products, Inc.
860 East Sandhill Avenue
Carson, CA 90746

The Honeywell Trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.