

Operation & Installation Guide



Office / Security Safes with Key Lock

DUPLICATE KEYS ARE NOT AVAILABLE FOR THESE SAFES

Models 5410, 5440, 5445, 5465

Read this manual carefully and never store it inside the safe!

Index

Welcome / Package Contents Page 1

**Using the Office - Security Safe /
Installing Adjustable / Removable Shelf**..... Page 2

Anchoring Your Safe / Care and Maintenance Page 3

Consumer Assistance..... Page 4

**DUPLICATE KEYS ARE NOT AVAILABLE / Safe Identification Record /
Notes** Page 5

Warranty Information..... Back
Cover

For Your Protection

- Do not remove the Serial Number tag from the safe.
- Never Store Access Keys inside safe.
- Record all Safe Identification Numbers on Safe Identification Record (page 5).
- Save this manual and NEVER keep it inside the safe.

WELCOME

Your new Honeywell Office / Security Safe will provide years of safe and secure protection for your valuables, important documents and other personal items. All Honeywell safes are designed and built using the highest manufacturing standards to ensure maximum user satisfaction under a variety of conditions. Your Honeywell safe will provide "Peace of Mind" for many years to come.

Thank you and enjoy!

PACKAGE CONTENTS


The following list outlines the items and quantities of each included with your new safe. Please carefully check the list to confirm all items have been received. If any item is missing, please contact Consumer Assistance. US/Canada 1-877-354-5457 (Toll Free)

Operation Manual (1 ea.)

Access Keys (2 ea.)

Adjustable / Removable Shelf (1 ea.) / Model 5465 (2 ea.)

Mounting Hardware (1 set)



Attention: DO NOT RETURN SAFE TO STORE

If you are missing parts or have difficulty operating your safe, please contact our Consumer Assistance Department by telephone. Store will not accept returned products without prior authorization. You must first contact our consumer assistance department. (See page 4 for contact information)

USING THE OFFICE / SECURITY SAFE

TO OPEN THE SAFE

1. Insert key into keyhole as shown (Figure 1).
2. Turn key clockwise to the right. Bolts will recede into safe door (Figure 2).
3. Pull door open using key (Figure 3).




Figure 1



Figure 2




Figure 3

TO CLOSE THE SAFE

1. Push door closed until it stops and turn key counter clockwise to the left (Figure 1).
2. Bolts will move into the locked position.
3. Remove key and store in a safe place away from the safe (Figure 2).




Figure 1




Figure 2

INSTALLING ADJUSTABLE / REMOVABLE SHELF

For additional convenience, this safe includes an adjustable shelf with 4 shelf clips. If you wish to use the provided adjustable shelf, follow the steps below. Otherwise store it and the clips in a safe location for later use.

SHELF INSTALLATION:

1. Hold each shelf clip in an upright position and insert into the pre-knotted holes located on the wall of the safe insuring that all 4 clips are equally inserted in height (Figure 1).
2. Lower each shelf clip into a horizontal position to lock it in place (Figure 2).
3. You must angle the shelf to install it inside the safe and then rotate it into position (Figure 3).
4. The shelf can then be placed to sit on top of each of the 4 shelf clips (Figure 4).




Figure 1




Figure 2




Figure 3




Figure 4

ANCHORING YOUR SAFE

You may mount your safe for added theft protection and resistance to tipping. 4 pre-drilled bolt-down holes provide the option of wall or floor mounting. Includes hardware for securing to concrete surfaces for maximum protection. If you desire to bolt the safe to other surface types such as wood or metal, additional hardware would be needed. Check with your local home center.

MOUNTING:

1. Determine first if wall mounting or floor mounting is desired and then position the safe in the location you would like to mount it in and open the safe door.
2. Carefully remove the mounting hole cover plugs using a flat-head screwdriver (Figure 1).
3. Place a pencil inside the 2 holes and mark the surface for drilling (Figure 2).
4. Remove safe so that you can see the markings you made and then using a drill with a 14mm bit, drill each hole to a depth of 45mm and remove any excess dust. (Figure 3).
5. Re-position safe over holes and insert the anchor bush with bolt and tighten (Figure 4).
6. Replace the mounting hole cover inside of safe over the 2 holes used (Figure 5).




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5

NOTE: Bolting/unbolting of the unit is at the consumer's expense and discretion. LH Licensed Products is not responsible for any costs incurred if the unit is to be replaced.

If you have any questions about mounting the safe, please check with your local home center/hardware retailer or independent contractor.

CARE AND MAINTENANCE

When properly maintained, your safe will continue to operate for many years. In order to ensure optimum performance of your safe, please follow these simple precautions:

CLEAN SAFE – To clean the surface of your safe, it is recommended that you use a mild cleaner (e.g., window cleaner) to avoid scratching or discoloring the surface. Always wipe dry and NEVER use abrasive cleansers on the safe or digital keypad.

MOISTURE – We recommend that you place delicate items such as pictures or intricate jewelry into an air-tight container before storing them in your safe. Avoid placing your safe in areas of high humidity. For optimum performance, the safe should be opened and aired out for at least 20 minutes every two weeks.

For future reference, store this Operation and Installation Guide in a secure area away from the safe. DO NOT DISCARD!

CONSUMER ASSISTANCE

EMAIL: LHLPCustomerService@LHLPinc.com

WEBSITE: www.honeywellsafes.com

ADDRESS: Consumer Assistance Dept.
LH Licensed Products, Inc. 860 East Sandhill Avenue Carson, CA 90746 USA

TELEPHONE: US/Canada 1-877-354-5457 (Toll Free)

Mexico 01-800-288-2872 After English voice recording stops you must then enter 800-860-1677 to complete your call. (Toll Free)

Australia 0011-800-5325-7000 (Toll Free)

Germany/New Zealand 00-800-5325-7000 (Toll Free)

Other Countries XX*-310-323-5722 (Toll Charges Apply)
XX*- Dial U.S. Country Code first

CALL CENTER HOURS: US/Canada 7am – 5pm (PST**) Mon – Fri (Subject to change)
CALL BACK HOURS: Other Countries 7am – 8pm (PST**) Mon – Fri (Subject to change)
PST**- Local time in Los Angeles, CA, USA

INTERNATIONAL CALL BACK HOURS:

If you need to speak with a consumer assistant and cannot contact us during the Call Center hours above, please send an email or leave a telephone message, including your Name, Telephone Number and the best time for us to contact you during the Call Back hours above and we will make every effort to contact you and help answer any of your questions or concerns.

* Insert correct Country Code

** Local Time based on Los Angeles California USA

DUPLICATE KEYS ARE NOT AVAILABLE

IMPORTANT: In order to maintain maximum security levels, duplicate keys are not available for the security / office safes referenced in this manual. If keys are lost the safe would have to be drilled open at the owners expense.

SAFE IDENTIFICATION RECORD

Model Number: _____

Serial Number: _____

NOTES

Limited Warranty

LH Licensed Products, Inc., ("LHLP, Inc.") warrants that for a period of seven (7) years from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser's sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value.

THIS IS YOUR EXCLUSIVE WARRANTY.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty service.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, earthquakes, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.



Manufactured by:
LH Licensed Products, Inc.
860 East Sandhill Avenue
Carson, CA 90746

The Honeywell Trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.