


## LONG GUN / EXECUTIVE SAFE



**READ THIS MANUAL CAREFULLY AND  
NEVER STORE IT INSIDE THE SAFE!**

## PACKAGE CONTENTS

- Operation Manual
- 2 Override Access Keys
- 1 Mounting Kit w/ Bolts
- 7 Removable Shelves
- 1 Gun Rack
- 24 Shelf Support Clips



## ATTENTION

### DO NOT RETURN SAFE TO STORE!

For missing parts or difficulty operating your safe, please contact our Consumer Assistance Department by telephone.

Store will not accept returned products without prior authorization. You must first contact our consumer assistance department.

US/Canada 1-877-354-5457 (Toll Free)

Mexico 01-800-288-2872 After English voice recording stops you must then enter 800-860-1677 to complete your call. (Toll Free)


Australia 0011-800-5325-7000 (Toll Free)

Germany/New Zealand 00-800-5325-7000 (Toll Free)

Other Countries XX\*-310-323-5722

XX\*- Dial U.S. Country Code first (Toll Charges Apply)

## LOCK OVERVIEW



LED Indicator Lights

Digital Keypad

Open/Close Knob

**IMPORTANT – TEST DIGITAL LOCK BEFORE INSTALLING!!**

## INSTALLING & REPLACING BATTERIES

**NOTE:** The pass code will not be erased if the batteries become weak or are removed.



Four alkaline AA batteries, (not included) are required to activate the keypad.

**NOTE:** Non-alkaline and rechargeable batteries **ARE NOT RECOMMENDED.**

Dead or weak batteries should always be removed promptly:

When changing batteries you must always replace all 4 batteries.

1. Using two hands, hold the keypad, thumbs down, on its left and right sides. Push up the keypad with your thumbs, and disconnect it from the safe by pulling it towards you (Fig. A).
2. Let the disengaged keypad hang by its wires. This will expose the battery holder (Fig. B).
3. Install four alkaline AA batteries as illustrated on the back of the battery holder.
4. **DO NOT USE** Non-alkaline or rechargeable batteries.
5. Ensure the batteries are installed in the correct direction with regard to polarity (+ and -).
6. Reconnect the keypad by inserting the keypad's three posts into the matching holes.
7. Push down to snap into place.
8. The yellow light will come on if your batteries become weak. If your batteries are dead and you cannot open the safe by using the digital keypad, you must use the override access key to open safe and access the battery compartment.
9. Do not close door before testing digital lock.



Remember to always remove batteries from safe if not using for an extended period of time.

## LED SIGNAL LIGHTS

Your electronic lock safe communicates by means of several audio/visual signals.

**Red - Error (A):**


1. Program key pressed out of sequence.
2. An invalid code or user pin entered.
3. 5 seconds or more between key presses.
4. Lights after three consecutive invalid codes are input (2-minute delay mode).

**Green - Proceed (B):**

1. After you enter a valid code, remains lit for 4-second period which safe can be opened.
2. Remains lit in Programming mode until finished entering a 5-digit code.

**Yellow - Low Battery (C):**

Comes ON when the batteries need to be replaced.



## SETUP & OPERATION

### PASS CODES

There are three ways to unlock and access the safe:

1. Preset Factory Code - You can always open the safe by entering the 5-digit Factory Code. This code cannot be deleted.
2. Programmed User Code - If you prefer to use your own code, you can program the safe to open to the 5-digit User Code of your choice.
3. Temporary User Code - If you wish to give someone temporary access, you can program a Temporary User Code that can later be erased.

### OPEN SAFE WITH FACTORY PRESET PASS CODE

1. Using the digital keypad enter the factory preset pass code as printed on the owners manual.
2. Rotate handle clockwise and open door.


### PROGRAMMING A USER CODE

There are two ways to program a user code.

1. Press the Program key (Prog.).
2. Enter the Factory Code and the green LED will remain on.
3. Enter 5-digit User Code of your choice.
4. After code is entered the green LED turns OFF.
5. Do not close door before testing new pass code.

OR

1. With door open, press red reset button inside door (Fig. 1).
2. The lock will “beep” and the green LED will come on.
3. Enter 5-digit User Code of your choice.
4. After code is entered the green LED turns OFF.
5. Do not close door before testing new pass code.  
To enter a new User Code, repeat these steps.



**Fig. 1**

### TEST NEW USER CODE

1. With door open, rotate handle counterclockwise to put door bolts in lock position.
2. Enter new code.
3. Green light is on; rotate handle clockwise within 5 seconds.
4. Lock bolts should recede into the unlocked position.

### PROGRAMMING A TEMPORARY USER CODE

1. Press the Program key.
2. Press it a second time.
3. Enter a 5-digit Code.
4. The green LED remains ON.
5. Enter 5-digit User Code of your choice (except 00000).
6. After code is entered the green LED turns OFF.

### DELETING A TEMPORARY USER CODE

1. Press the Program key.
2. Press it a second time.
3. Enter your 5-digit USER CODE.
4. Enter 0-0-0-0-0.
5. Temporary User Code has been erased.

### TO CLOSE THE SAFE

1. Make sure the lock bolts are in the unlocked position.
2. Close the door and hold it in the closed position.
3. Rotate handle counterclockwise to engage the bolts and lock safe.

## SECURE LOCKOUT PERIODS

If a wrong code is entered three times in a row, the digital keypad will begin a 2 minute secure lockout period. During this secure lockout period the keypad will become disabled. Once the lockout period has expired, the safe can be unlocked using the correct pass code.

## OVERRIDE ACCESS KEY

Your safe is equipped with an emergency key lock, which allows immediate access in case you forget your Pass code or the batteries need replacing.

1. Using two hands, hold the keypad, thumbs down, on its left and right sides. Push up the keypad with your thumbs, disconnect and remove the battery holder.
2. Insert the skeleton key into the key hole inside the opening for the battery.
3. Turn the key to the right.
4. Rotate the lever handle clockwise to the right, and then pull the door open.
5. After re-programming or changing batteries, replace the keypad and store keys in a safe and secure location away from the safe.

**IMPORTANT:** The override key is used to gain access to the safe to change batteries or if the digital lock fails to operate. This key should be stored in a secure place away from your safe.

## SAFETY PRECAUTIONS

The safe door is heavy. Do not open the door with the safe on an uneven or unstable floor. Hanging on an open door may cause the safe to tip forward when not lag-bolted to the floor, resulting in serious injury or death to yourself or others. If you have or have occasion to have small children in your home, please make sure you never leave your safe unsecured. It is possible for small children to climb inside your safe and become locked in. This could result in serious injury or death.

## MOVING YOUR SAFE

Before moving your safe, verify the load bearing weight of the floors and stairs, and types of flooring the safe will be moved over (tile, wood, and other flooring can be damaged by the weight of the safe). To determine whether or not your safe will make it through doorways, stairs or corners take the empty safe box and see if it will fit all the way through to its final location.

## PLACEMENT OF YOUR SAFE

Proper installation and anchoring are critical to the security of your safe. Install near a load-bearing wall to support the weight of the safe. To help protect the exterior finish of your safe, install inside in a dry location where there is climate control (heat in the winter and cooling in the summer).


## ANCHORING YOUR SAFE

You may bolt the safe to the floor to increase protection from theft and resistance to tipping. This safe was manufactured with bolt down holes pre-drilled in the floor panel. To secure your safe to the floor:

1. Locate the pre-drilled holes on the floor panel.
2. Anchor the safe using the mounting hardware kit which includes (2) lag screws and anchors.

**NOTE:** Bolting/unbolting of the unit is at the consumer's expense and discretion. LH Licensed Products is not responsible for any costs incurred if the unit is to be replaced.

If you have any questions about mounting the safe, please check with your local home center/hardware retailer or independent contractor.



## INSTALLING SHELVES

This safe includes (7) adjustable/removable shelves and (1) gun rack.

To install:

1. Remove shelves, gun rack and (24) shelf support clips from protective wrapping.
2. Each shelf will require (4) support clips.
3. Determine the desired location of your shelf and/or gun rack and note the corresponding support guide slots on the vertical standards that are best suited to support the shelf in that location.
4. Insert (1) support clip into each of the vertical standards. The top of the support clip should be placed into the selected slot first and then the bottom of clip will lock in place when pushed back.  
**IMPORTANT:** Make sure all (4) clips are installed at the same height on the vertical standards so that the shelf is level.
5. Install the shelf into position by placing inside the safe (tilting if necessary) and lowering into position on the support clips.
6. Repeat procedure for 2<sup>nd</sup> shelf.  
**HINT:** If shelves are not being used, they can be stored in the bottom of the safe.

## LOADING YOUR SAFE

Store documents and ammunition in the bottom of the safe for greatest protection against fire damage. If you are storing electronic media, use a Media Cooler (not included) to provide additional protection. Do not put anything in your safe that will put pressure against the door when it is closed. If you live in a humid environment, it is recommended that you use a dehumidifier or desiccant to protect the contents from rust or mildew.

## ORDERING NEW / REPLACEMENT KEYS

The following information is required to order keys:

### 1. PROOF OF OWNERSHIP (1 of 2 Options Below)

#### SALES RECEIPT & IDENTIFICATION – INTERNATIONAL ORDERS ONLY!

- Copy of sales receipt showing Store, Date & Product Description.
- Copy of your picture I.D. (Drivers license, passport, regular I.D.).

#### PRODUCT OWNERSHIP VERIFICATION FORM

If sales receipt is not available, contact us by email or telephone to request a "Product Ownership Verification Form".

### 2. ORDER INFORMATION

#### CONTACT INFORMATION

- Name & Shipping Address
- E-mail address (If Available)
- Telephone Number
- Best Time to Contact You

#### PRODUCT INFORMATION

- Safe Model #
- Safe Serial #
- Lock Key #
- Quantity of Keys Ordered

### 3. METHOD OF PAYMENT

- Telephone:  
Visa or MasterCard
- Mail:  
Check or Money Order

NOTE: For pricing please contact Consumer Assistance.  
Contact information is located on the back cover of this manual.

Terms subject to change without prior notification.

## LOCATING SAFE IDENTIFICATION NUMBERS

When contacting Customer Service you will need to provide the following information:

#### SERIAL NUMBER

Located on lower right corner on front of safe.  
Do Not Remove Safe I.D. Tags!



## LIMITED WARRANTY

LH Licensed Products, Inc., (“LHLP, Inc.”) warrants that for a period of seven (7) years from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser’s sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. **THIS IS YOUR EXCLUSIVE WARRANTY.**

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty service.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.

## CONSUMER ASSISTANCE

EMAIL (Best Contact Method): LHLPCustomerService@LHLPinc.com

WEBSITE: www.Honeywellsafes.com

ADDRESS: Consumer Assistance Dept.  
LH Licensed Products, Inc.  
860 East Sandhill Avenue  
Carson, CA 90746 USA

TELEPHONE: US/Canada 1-877-354-5457 (Toll Free)  
Mexico 01-800-288-2872 After English voice recording stops you  
must then enter 800-860-1677 to complete your call. (Toll Free)  
Australia 0011-800-5325-7000 (Toll Free)  
Germany/New Zealand 00-800-5325-7000 (Toll Free)

Other Countries XX\*-310-323-5722 (Toll Charges Apply)  
XX\*- Dial U.S. Country Code first

CALL CENTER HOURS: US/Canada 7am – 5pm (PST\*\*) Mon – Fri

CALL BACK HOURS: Other Countries 7am – 8pm (PST\*\*) Mon – Fri  
PST\*\*- Local time in Los Angeles, CA, USA

### INTERNATIONAL CALL BACK HOURS:

If you need to speak with a consumer assistant and cannot contact us during the Call Center hours above, please send an email or leave a telephone message, including your Name, Telephone Number and the best time for us to contact you during the Call Back hours above and we will make our best effort to contact you and help to answer any of your questions or concerns.



Manufactured by  
LH Licensed Products, Inc.  
860 East Sandhill Avenue  
Carson, CA 90746

The Honeywell Trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.