


DIGITAL STEEL SECURITY BOX



Read this manual carefully and never store it inside the box!

Digital Steel Security Box

PACKAGE CONTENTS

- 1 – Digital Steel Security Box
- 1 – Operation Manual
- 2 – Emergency Override Keys
- 4 – “AA” Batteries

ATTENTION

DO NOT RETURN SAFE TO STORE!

For missing parts or difficulty operating your safe, please contact our Consumer Assistance Department by telephone.

Store will not accept returned products without prior authorization. You must first contact our consumer assistance department.

US/Canada 1-877-354-5457 (Toll Free)

Mexico 01-800-288-2872 After English voice recording stops you must then enter 800-860-1677 to complete your call. (Toll Free)


Australia 0011-800-5325-7000 (Toll Free)

Germany/New Zealand 00-800-5325-7000 (Toll Free)


Other Countries XX*-310-323-5722

XX*- Dial U.S. Country Code first (Toll Charges Apply)

PRODUCT OVERVIEW



- A - Emergency Key Cover
- B - Open/Close Knob
- C - Keypad
- D - LED Indicator
- E - Box Lid
- F - Carry Handle
- G - Box Body




- H - Box Lid
- I - Battery Compartment
- J - Reset Button

SETUP & OPERATION

STEP 1: OPEN SECURITY BOX & INSTALL BATTERIES

For your convenience, we have included 4 "AA" Batteries that provide the power for the electronic keypad. These must be installed before using your box. If your safe is locked, you may use the Emergency Key to open it.

1. Remove the Black Emergency Key Cover.
2. Insert the Emergency key and turn ¼ turn to the left (counterclockwise).
3. Turn the Open/Close knob ¼ turn to the left (counterclockwise) and open the lid.
4. Remove the Battery Compartment cover by pushing in and sliding down.
5. Install the batteries as pictured on the inside of the Battery compartment. Ensure the batteries are installed in the correct direction, with regard to polarity (+ and -)
6. Once the batteries are properly installed, replace the battery compartment cover. Close Lid, Return Knob & Key to "Locked" position and replace Emergency key cover.



IMPORTANT: The starter batteries included with this product are for testing purposes only and should be immediately replaced with new alkaline or lithium batteries. It is **NOT RECOMMENDED** to use Non-alkaline or rechargeable batteries.

NOTE: If batteries are removed or fail, the keypad memory will **NOT** be erased and the active programmed code will still work once power has been restored.


Weak or dead batteries should be replaced immediately and all 4 batteries should be changed. To replace the batteries please follow the instructions in the SETUP section. Remember to always remove batteries from safe if not using for an extended period of time. If your batteries are completely dead and you cannot open the safe by using the digital keypad, use the override access key to open safe and access the battery compartment.

SETUP & OPERATION

STEP 2: OPEN THE BOX AND RESET PASSCODE

The preset factory user code is 3 *.

1. Enter the factory preset code and you will see the LED light turn green.
2. Turn the Open/Close knob ¼ turn to the left (counterclockwise) and open the lid.
3. To program a new code, press the red reset button on the right side of the battery box. The LED light will flash Orange.




4. Enter a new code (up to 5 digits), followed by the * key and repeat a second time.
Example: 1 - 2 - 3 - 4 - 5 - * - 1 - 2 - 3 - 4 - 5 - *.
After the first set the LED will flash orange and after the second it will flash green indicating that you have successfully reprogrammed the code.

SETUP & OPERATION

STEP 3: LOCK THE SAFE:

Close the Lid and make sure that the Open/Close Knob is in the Locked position.



ORDERING NEW / REPLACEMENT KEYS

The following information is required to order keys:

1. PROOF OF OWNERSHIP (1 of 2 Options Below)

SALES RECEIPT & IDENTIFICATION – INTERNATIONAL ORDERS ONLY!

- Copy of sales receipt showing Store, Date & Product Description.
- Copy of your picture I.D. (Drivers license, passport, regular I.D.).

PRODUCT OWNERSHIP VERIFICATION FORM

If sales receipt is not available, contact us by email or telephone to request a “Product Ownership Verification Form”.

2. ORDER INFORMATION

CONTACT INFORMATION

- Name & Shipping Address
- E-mail address (If Available)
- Telephone Number
- Best Time to Contact You

PRODUCT INFORMATION

- Safe Model #
- Safe Serial #
- Lock Key #
- Quantity of Keys Ordered

3. METHOD OF PAYMENT

- Telephone:
Visa or MasterCard
- Mail:
Check or Money Order

NOTE: For pricing please contact Consumer Assistance.

Contact information is located on the back cover of this manual

Terms subject to change without prior notification.

LOCATING SAFE IDENTIFICATION NUMBERS

SERIAL NUMBER

Located on lower right corner on front of safe. Do Not Remove Safe I.D. Tags!



KEY NUMBER


4 Digit Number etched on the metal collar located around the key hole.



MODEL 6110 - ATTACHING SECURITY CABLE


1. Remove plug from hole on the outer left side of the box.

1.




2. Wrap cable around object and back through looped end.

2.




3. Depress cable release button and hold down.

3.



4. Insert security cable into the hole and release button.

4.



LIMITED WARRANTY

LH Licensed Products, Inc., (“LHLP, Inc.”) warrants that for a period of one (1) year from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser’s sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value.

THIS IS YOUR EXCLUSIVE WARRANTY.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty service.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.

CONSUMER ASSISTANCE

EMAIL (Best Contact Method): LHLPCustomerService@LHLPinc.com

WEBSITE: www.Honeywellsafes.com (Effective April 15, 2013)

ADDRESS: Consumer Assistance Dept.
LH Licensed Products, Inc.
860 East Sandhill Avenue
Carson, CA 90746 USA

TELEPHONE: **US/Canada** 1-877-354-5457 (Toll Free)
Mexico 01-800-288-2872 After English voice recording stops you must then enter 800-860-1677 to complete your call. (Toll Free)
Australia 0011-800-5325-7000 (Toll Free)
Germany/New Zealand 00-800-5325-7000 (Toll Free)


Other Countries XX*-310-323-5722 (Toll Charges Apply)
XX*- Dial U.S. Country Code first

CALL CENTER HOURS: **US/Canada** 7am – 5pm (PST**) Mon – Fri

CALL BACK HOURS: **Other Countries** 7am – 8pm (PST**) Mon – Fri
PST**- Local time in Los Angeles, CA, USA

INTERNATIONAL CALL BACK HOURS:

If you need to speak with a consumer assistant and cannot contact us during the Call Center hours above, please send an email or leave a telephone message, including your Name, Telephone Number and the best time for us to contact you during the Call Back hours above and we will make our best effort to contact you and help to answer any of your questions or concerns.



Manufactured by
LH Licensed Products, Inc.
860 East Sandhill Avenue
Carson, CA 90746

The Honeywell Trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.